



This document explains how to move the SiteWatch™ server software to a new server computer without having to rebuild the sites and maps.

Follow these steps to move the SiteWatch™ server software to a new server computer. If you plan to upgrade the SiteWatch server software as well, first perform the upgrade on the old server then move the updated software to the new server.

1. Export the old server Registry key HKEY_LOCAL_MACHINE\SOFTWARE\e-Watch.
2. Remove the USB security key from the old server, and insert it into the new server.
3. Install SiteWatch on the new server.
4. Stop the e-Watch service on the new server.
5. Copy the folder “C:\e-Watch” from the old server to the new server.
6. On the new server, import the Registry file created in step 1.
7. Change the IP address of the old server.
8. Change the IP address of the new server to the old server’s original IP address.
9. Start the e-Watch service on the new server.

e-Watch Corporation
7800 IH-10 West, Suite 720
San Antonio, TX 78230
USA

tel: (210) 349-2000
fax: (210) 341-1020

For more information:

email:
sales@e-watch.com

website:
www.e-watch.com

Copyright© 2009 e-Watch Corporation. All rights reserved. e-Watch is a registered trademark of e-Watch Corporation. ViewWatch, Decision-Watch, EventWatch, SiteWatch, MotionWatch, GateWatch, AirWatch, PocketWatch, PeopleWatch, BankWatch, ClassWatch, ObjectWatch, WatchLink, Activity Gated Storage, and Gigapixel are trademarks of e-Watch Corporation. Any other trademarks mentioned in this document are the property of their respective owners. The use of the word partner does not imply a partnership relationship between e-Watch Corporation and any other company.